



# Active Installation Guideline





### 1. Power the device

Power the device on by pressing and holding the centre button for 10 seconds



### 2. Ensure sensor is on

2 flashes of the green light means sensor is now on. Ensure the installation area is clean



### 3. Placement

Place the sensor on the outside of the equipment, as close to the motor as possible















